FIELD CLASS TRACTOR PULL

Saturday, August 5 • 3:00 p.m.

One pass allowed per tractor.

NOTE: Entry forms available at the Washington Area Chamber of Commerce Office. Forms must be returned to the Chamber Office at the address indicated on or before Friday, July 28, 2023. Classes will be limited to the first 20 entries only. Entries not pre-registered will not be accepted at the weigh-in--ABSOLUTELY NO EXCEPTIONS. Please print/type name, address and zip on all entry forms.

DUE TO CROWDED CONDITIONS, TRAILERS & TRUCKS FOR FIELD CLASSES <u>WILL NOT</u> BE ABLE TO PARK ON THE GROUNDS!

NOTE: TIEMANN DR. WILL BE CLOSED FROM NORTH PARK DR. TO VETERANS DR.

ALL Tractors must be weighed in between 10:00 a.m. and 1:00 p.m. Tractor pull contestants are required to remove their tractors from the grounds after all Field Classes are completed. Parking for tractors is at the old Fire Training Center on Westlink Dr. From arena take Tiemann Dr., then left onto Main St., left on Westlink to the training center on the left. The old Fire Training Center will be marked with signs. Any exceptions must be cleared with a member of the Tractor Pull Committee. This request is to reduce congestion on Friday. Thank You.

RULES AND REGULATIONS

- Contest will be limited to field class tractors only. NO tire chains, rear duals or four-wheel drives allowed. NO hand-cut or hand sharpened tires allowed.
- 2. ENTRY FEE of \$20 per class entry, with 100% payback in each class.
- ALL TRACTORS MAY ENTER I CLASS ONLY. CLASSES:
 - A) 0-6,000 lbs.* 60 HP 15.5x38 tire size**
 - B) 6,001-7,500 lbs.* 75 HP 16.9x38 tire size**
 - C) 7,501-9,500 lbs.* 95 HP 18.4x38 tire size**
 - D) 9,501-11,500 lbs.* 125 HP 20.8x38 tire size**
 - E) 11,501-13,500 lbs.* 155 HP 20.8x42 tire size**
 - F) 13,501-17,000 lbs.* 180 HP 24.5x42 tire size**

*Weight of tractor includes driver

**Tires must be of proper size or the equivalent.

Formula to determine equivalent: (width x 2) + diameter

- 4. Drawbar height limit will be 21 inches. Minimum length of drawbar will be 20 inches from center of rear axle. All tractors must use clevis with 3-inch opening or hitch with 3-inch opening allowing hook to swing free.
- 5. Rear tractor weights cannot interfere with hooking of sled. Three pt. weights must be turned so the heaviest side is to the inside of tractor-not sled.
- 6. FUEL: One fuel only Gas, LP, or Diesel. Only factory fuel pumps for make and model of tractor.
- 7. A dynamometer will be used to check the top five (5) pullers in each class. All tractors must have PTO shaft. All tractors over 120 HP must have 1,000 RPM-PTO shaft. Engines not to exceed 10% above factory governed high-idle on tractors with a factory governed high-idle in excess of 2,000 RPM and 20% above factory governed at less than 2,000 RPM. High-idle and PTO-HP will be determined by a dynamometer using the Nebraska Test Book as a guideline for the make, model, and serial number for that tractor regardless of engine. NO tolerance will be allowed on HP and RPM. All hand and/or foot throttles may be checked for proper operation at judges discretion.
- 8. Removal of items such as hoods and other items which may create a safety hazard will not be allowed. All tractors must use two front wheels.
- 9. All weights must be bolted or securely fastened to the tractor. Any loss of weights will result in disqualifiction. Any front-end weight cannot extend more than 24 inches in front of the factory hood of the tractor.
- 10. Fan belts must be connected and running air intakes must be through a standard-factory air cleaner (both inner and outer air filter.)
- 11. Contestants under 21 years of age must have written consent of parent or guardian.
- 12. No persons will be allowed in the arena other than tractor operators and contest officials.
- 13. The Pull is ended when any of the following occur:
 - (a) Forward motion of tractor stops.
 - (b) Driver does not remain seated.
 - (c) Tractor or sled does not stay within the pulling strip or tractor hitch breaks.
- 14. If a puller is not ready when his turn comes, he can forfeit his turn and pull last in that class.
- 15. Unsportsmanlike conduct before, during or after tractor pull will mean disqualification, also forfeiture of entry fee plus prize money won.

- 16. First hitch of each class has the choice of repull. If repulling, you must tell judges before unhooking from the sled. Last pull is measured. If sled is not readjusted before the fourth tractor pulls in each class, class will be official.
- Entry forms must be received by Friday, July 28, 2023.
 Classes will be limited to the first 20 entries only.
- 18. Tractor must be weighed in at Fairgrounds. Weigh-in time will be from 10 a.m. to 1 p.m. on Saturday, August 5, 2023. There will be no charge for weigh-in. Contest will begin at 3:00 p.m. in the Motor Sports Arena at the Fairgrounds.
- Caution must be exercised at all times. Failure to comply with safety procedures may result in disqualification.

- 20. All disabled tractors must be removed from the track prior to the next tractor pulling. The committee will do what is deemed necessary to remove the tractor.
- 21. All protests must be made before the final weight check. Protests can only be made by a contestant in the same weight class. Tractors will be identified by class and pull order. Pull is official unless tractor is checked to be over horsepower.
- 22. Dyno will stop at 2:30 p.m.
- 23. The Tractor Pull Committee will have final decision on all questions, disputes, hardship cases, etc., that may develop.
- 24. <u>ALL</u> Field Class tractors must be removed after all Field Classes are finished and the tractor has had Dyno check.

**Absolutely No unauthorized personnel will be allowed on the track. Beer and soda will be available for purchase in the tractor pull area. Please NO BOTTLES, CANS OR COOLERS on the grounds due to safety of the public and tractor or truck tires.

One UNOPENED plastic WATER BOTTLE will be allowed per person. THANK YOU!





www.washmofair.com 45